






GALAKSİ FLOTÖR MONTAJ TALİMATI

GALAKSİ INLET VALVE INSTALLATION MANUAL



SU SEVİYESİ
WATER LEVEL